



How to safely isolate the Fuse board

1. Turn off each MCB/RCBO one by one starting with the smallest loads (i.e 6 amp lighting circuits)
2. Turn off RCDs (If present)
3. Turn off large RED Main Switch

Do NOT

Touch the fuse board if a burning smell or cracking/sparking sound can be heard

In an Emergency call 999

0757 075 0101 020 7096 7975

www.optycsolutions.com